

pure indoor living



## **Instruction Leaflet**

Read instructions before operating. Retain for future reference.



Questions? Comments? Call 1-800-253-2764 in North America.

# PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this heater.

- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- 4. Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.

- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside.
   Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- 13. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/ receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- When unplugging, be sure to pull by the plug and not the cord.
- If the heater will not operate, see specific instructions on Auto Safety Shut-off.
- 17. DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- Discontinue use if plug or outlet is hot. It is recommended that the outlet be replaced if plug or outlet is hot to touch.
- 19. The heater must not be located immediately below a socket-outlet. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- WARNING: In order to avoid overheating, do not cover the heater.
- WARNING: This heater is not equipped with a
  device to control the room temperature. Do not use
  this heater in small rooms when they are occupied by
  persons not capable of leaving the room on their
  own, unless constant supervision is provided.



THIS APPLIANCE HAS A POLARIZED PLUG (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.

DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.

### FEATURES - OPERATIONS

## SAVE THESE INSTRUCTIONS

#### **TECHNICAL SPECIFICATIONS**

Amps: 12.5


Wattage: 1500W (+5% -10%)
 Working voltage: 120V AC/60Hz

#### **OPERATING INSTRUCTIONS**

 Carefully remove your heater from the box. Please save the carton for off-season storage.

2. Place heater on firm level surface.

- 3. Avoid overloading your circuit by not using other high wattage appliances in the same outlet. At 1500 Watts, this unit draws 12.5 Amps.
- 4. There is a cord wrap at the bottom of the heater to hide extra cord or wrap the cord for storage.



#### Mode Control

Turn the Mode Control to the desired setting:

#### OFF - Off Mode

If you want to shut off the heater at any time during operation, turn the Mode Control to OFF position. Power Light will remain lit until the heater is unplugged.

#### 1 - LOW Heat

The heater will run continuously at 750W.

#### 2 - HIGH Heat

The heater will run continuously at 1500W.

**NOTE:** To start the heater operation, make sure the Thermostat Control is turned fully clockwise to the highest position (7).

### Rotating Grill Oscillation

This heater has rotating grill oscillation feature. To activate, turn the Mode Control left to the High/Low (2/1) settings. When rotating, the heat flow will cover a wider area and help to circulate heat throughout the room. To stop rotating grill, turn the Mode Control right to the High/Low (2/1) settings.

**NOTE:** The grill may spin in both directions. If the grill is touched while rotating, the grill may spin in the opposite direction. This is normal and does not affect the rotating grill feature.

#### Thermostat Control

- Before setting the thermostat, allow heater to operate and warm up the room. Set the thermostat to the highest setting (7) to start the heater.
- When the desired temperature comfort level is reached, lower the thermostat setting until the fan/ heater stops operating. This is done by turning the Thermostat Control counter-clockwise and select from the 7 temperature levels (1-7).

**NOTE:** It is normal for the heater to cycle ON and OFF as it maintains the preset temperature. To prevent the unit from cycling, turn the thermostat control clockwise to the highest setting (7).

## CLEANING / MAINTENANCE TROUBLESHOOTING

#### **AUTO SAFETY SHUT-OFF**

This heater is equipped with a patented, technologically advanced, safety system that requires the user to reset the heater if there is a potential overheat situation. When a potential overheat temperature is reached, the system will automatically shut the heater off. It can only resume operation when the user resets the unit.

#### To Reset the Heater:

- 1) Turn Control to OFF.
- 2) Unplug the unit and wait 30 minutes.
- 3) Plug in and operate normally.

#### **CLEANING/MAINTENANCE**

Always unplug the heater before cleaning and allow the heater to cool down.

- Clean the unit with a soft cloth moistened with a mild soap solution.
- NEVER use abrasive or flammable solvents to clean the unit.
- 3. After cleaning, be sure to completely dry the unit with a cloth or towel.
- 4. Store heater in a cool, dry location.
- It is recommended that you store the unit in its original carton.

#### **TROUBLESHOOTING**

If your heater fails to operate:

- Turn the heater OFF and UNPLUG THE HEATER.
- Make sure the electrical outlet or circuit breaker is working.
- Check for obstructions. If you find an obstruction turn the heater OFF, and unplug the unit. Carefully remove the obstruction and follow the reset instructions.
- The temperature may be set too low. Turn the Thermostat Control to a higher temperature level until the heater restarts.
- Make sure to follow the above instructions to turn on the heater and set the digital thermostat to your precise comfort level.

Please DO NOT attempt to open or repair the heater.

If you have any questions regarding your product or would like to learn more about other Bionaire® products, please contact our Consumer Service Department at 1-800-253-2764 or visit our website at <a href="https://www.bionairecanada.com">www.bionairecanada.com</a>. For inquiries regarding recycling and proper disposal of this product, please contact your local waste management facility.

### WARRANTY INFORMATION

#### 1 YEAR LIMITED WARRANTY

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions or if in Canada, Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "JCS") warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. JCS, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. JCS dealers, service centers, or retail stores selling JCS products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than JCS or an authorized JCS service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

#### What are the limits on JCS's Liability?

JCS shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

JCS disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

JCS shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

#### **How to Obtain Warranty Service**

#### In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-800-253-2764 and a convenient service center address will be provided to you.

#### In Canada

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-800-253-2764 and a convenient service center address will be provided to you.

## WARRANTY INFORMATION

In the U.S.A., this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, located at 20 B Hereford Street, Brampton, Ontario L6Y 0M1. If you have any other problem or claim in connection with this product, please write our Consumer Service Department. PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.

<sup>© 2014</sup> Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved. Imported and distributed by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, 20 B Hereford Street, Brampton, Ontario L6Y OM1.